


## TrueGuard-PRO Basler DGC2020 Iridium Installation Guide

- Unpack the monitor, antenna and the data/power cable. The 25-pin connector plugs onto the front of the OmniMetrix<sup>®</sup> monitor. This cable includes wires to power the monitor as well as wires for alarm inputs, relay outputs and analog inputs. Take a moment to inspect all components to verify there is no shipping damage.
- 2. Place the Iridium Antenna outside with a clear view of the sky. BE SURE to provide a drip loop lower than the monitor to keep water from running down the antenna cable into the monitor connection.
- 3. Attach the monitor via its magnetic feet, on top of the engine controller or other appropriate location. Horizontal surfaces are best, but the unit may be mounted vertically or even upside down if necessary. *Note: If mounted vertically, install the monitor with the cables down to prevent water from entering the enclosure.*
- 4. Route the data/power cable into the generator control enclosure.
- 5. The monitor wires to the Basler Terminal Board using the wiring definitions as shown in Table 1 (next page).
- 6. Attach the antenna cable to the front of the monitor, and tighten thumb tight.
- 7. Turn on the monitor and confirm that the LEDs light up and blink. If not, check for power on the terminal strip. If, after 5 minutes, the only LED lit is the Power LED, check the antenna mount and cable connection.
- 8. Allow 15 minutes for the monitor to log into the network and then call OmniMetrix at 770-209-0012 to confirm installation. Access to machine data is through the OmniView<sup>®</sup> web interface at <u>www.omnimetrix.net</u>. Contact OmniMetrix for login instructions and web training.



Iridium Antenna



Data/Power Cable



DGC2020 Controller




DGC2020 Wiring

MTU Basler Wiring Installation		
OMN Wire	Function	Basler Terminal
Red	Gen Battery +	3
Black	Gen Battery GND	2
White	RS485 Data +	13
Green	RS485 Data -	14

Table 1 – TrueGuard-PRO Basler DGC2020 Wiring Table

If 2-wire remote start is desired, use OmniMetrix White/Yellow and White/Brown wires across the 2-wire start terminals.



If you have any questions, please call OmniMetrix Tech Support at 770-209-0012 or email at techsupport@omnimetrix.net.

