

NOTE: Interrupting N1 or N2 in this method will cause the ATS to transfer house load to the generator. While the transfer will be immediate, there is always a risk of glitching the homeowner's electrical equipment and appliances. Utilizing the remote start method should only be done with customer approval.

NOTE: N1 and N2 are HOT !!! Pull the main breaker and confirm there is no voltage on them before following this installation !!!

