

Alarms	Analog Parameters
Data Connection Lost	Battery Voltage
Generator Running	Engine Hours <sup>1</sup>
Generator Excessive Running <sup>1</sup>	
Fail to Exercise <sup>1</sup>	
Battery Voltage High <sup>2</sup>	
Battery Voltage Low <sup>2</sup>	
Common Alarm <sup>3</sup>	
Not In Auto <sup>3</sup>	
Oil Pressure Low <sup>3</sup>	
Coolant Temp High <sup>3</sup>	
Generator Supplying Load <sup>3</sup>	
Controls	
Remote Start/Stop (if activated by customer)	

All Alarms & Analog Parameters noted above are only available if so configured at Generator and ATS control panel.

It is recommended that a technician with communications experience be utilized to install and calibrate any optional OMNIMETRIX accessories.

<sup>1</sup> Generator Excessive Running, Fail to Exercise, and Engine Hours are available when configured through OmniView™. It is suggested to do this at time of monitoring setup.

<sup>2</sup> Battery Voltage High & Low Alarms based upon Battery Voltage Threshold settings set up in OmniView™.

<sup>3</sup> Alarms require programming using Thompson Technology Software and communication cable. Customer is responsible for having proper software and connection cables at time of install. The above Thompson Technology Alarms are the standard Alarms selected by OMNIMETRIX. See Thompson Technology MEC2/20 Control Panel Manual for further information.